FIRMWARE 2.05 RELEASE NOTES   (HW2 ONLY)

OVERVIEW

Added support for full memory usage, flashing UFLC carts, and USB FIFO capabilities.

Refer to the 2.00 Release Notes if you are currently upgrading from 1.xx firmwares. This only describes changes from the previous version.

FULL CHANGES

1. New extended address mode allows use of 240MB mapped cartridge space and relocates CI registers. See Hardware Usage Guide for details.
2. Additional standalone PI commands added to enable flashing UFLC boards.
3. Basic USB FIFO pipe functionality added. See Hardware Usage Guide for details.

HOW TO UPGRADE

First, check to see what firmware version you currently have, by opening the "About" tab in the 64drive menu.

- **You have 1.00-1.05:**
  You must upgrade using the **Easy Upgrader**, or the **command line USB Loader 1.xx** tool.
  Refer to the 2.00 Release Notes for instructions on how to use the command line tool.

- **You have 2.00-2.04:**
  Simply copy the "64drive_firm_205.rpk" file from the website onto your memory card.
  Load the file in the menu as if you were starting a game, and your firmware will be upgraded.
  You should have at least Menu 1.12c for this method.

  Alternatively, you can use the command line USB Loader 2.xx tool to upgrade via USB.

END OF DOCUMENT

REVISION INFORMATION

January 4, 2018   Wide release

COPYRIGHT INFORMATION