

FIRMWARE 2.03 RELEASE NOTES

OVERVIEW

Added standalone mode functions for UltraSave.

Refer to the 2.00 Release Notes if you are currently upgrading from 1.xx firmwares. This only describes changes from the previous version.

FULL CHANGES

1. Add USB mode commands for doing master bus operations on both PI and SI cart busses.
2. Support for UltraSave adapter board.

HOW TO UPGRADE

First, check to see what firmware version you currently have, by opening the “About” tab in the 64drive menu.

- **You have 1.00-1.05:**
You must upgrade using the **Easy Upgrader**, or the **command line USB Loader 1.xx** tool.
Refer to the 2.00 Release Notes for instructions on how to use the command line tool.
- **You have 2.00-2.02:**
Simply copy the “64drive_firm_203.rpk” file from the website onto your memory card.
Load the file in the menu as if you were starting a game, and your firmware will be upgraded.
You should have at least Menu 1.12c for this method.

Alternatively, you can use the command line USB Loader 2.xx tool to upgrade via USB.

END OF DOCUMENT

REVISION INFORMATION

| | |
|-------------------|-----------------|
| February 26, 2016 | Limited release |
| November 16, 2016 | Wide release |

COPYRIGHT INFORMATION

© 2011-2016 Marshall H / Retroactive

<http://64drive.retroactive.be/>

"Nintendo" is a registered trademark of Nintendo of America Inc.

Nintendo 64 is a registered trademark of Nintendo Company, Limited

This product is not endorsed or supported by Nintendo. Use the device at your own risk.

To submit any inaccuracies or inconsistencies in this document, please e-mail support at the above web address.